

Liberty Swing

Technical Fact Sheet – with US conversion

Swing measurements:	4.0 m (13.12 ft) long x 3.2 m (10.5 ft) wide; on/off device measures 1.2 m (3.9 ft). The Liberty Swing is 3.1 m (10.1 ft) at its highest point.
Area required:	Minimum 27 sq m (290 sq ft) is required to meet Australian standards; Width: 2.9 m (9.5 ft) between support posts; Length: 3.8 m (12.47 ft) each side of crossbar 7.6 m (24.93 ft) total
Fall Zone/Height:	The manufacturer recommends a fall height of 1.8 m (5.9 ft)
Delivery	Most deliveries are despatched from Australia within 6 weeks from date of order. The Liberty Swing is packaged for delivery weighing approx 360 kg (793.6 lb) net; with packaging, 380 kg (837.7 lb).
Swing Components/Locks:	<ul style="list-style-type: none">- Capsule with internal seat, on/off device lock, wheel locks, seat belt and seat belt anchor points, seat belt locking compartment- On/off device with torsion rod- Top swing cross bar- Capsule support arms (4)- Post legs (4) and extensions (6)- MLA key (2)- Signage:<ul style="list-style-type: none">o Restricted areao How to Start/Finish Rideo Liberty Swing panels
Installation Instructions:	Full Manual is supplied on order of the Liberty Swing and includes: <ul style="list-style-type: none">- General assembly plan and side elevations- Installation instructions- Soft fall instructions- Components list- Suggested fence layout plan- Maintenance program
Australian Standards Compliance:	AS4685:2004 AS 2555 Guide to Siting, Installation, Maintenance AS/NZS 4486-1 Development, Installation, Inspection and Operation
US Standard	The Liberty Swing is sold as ‘therapeutic equipment’ and has incorporated safety components as far as possible to meet ASTM requirements. ADA compatible.
European Standard	EN1176 Certification granted October 2008
Manufacturer’s warranty:	Jenway Industries offer a 5 year warranty with normal usage